

Covers for switches/push-buttons
Cover plate
with rotary control, with marking



As cover for flush mounted three-step rotary switch.
With zero position.
For insert 2710 U.

Order Code : 2CKA001710A3108
Article No. : 2542 DR/01-212
EAN: 4011395990186