
SBitDo


Ultimate 2.4G wireless Controller

English

猎户座 2.4G 无线手柄

中文





- * 开机: 按下 home 键。
- 关机: 按住 home 键 3 秒。
- 强制关机:按住 home 键 8 秒。
- 手柄置于底座时会自动关机。
- 可将 2.4G 接收器 插入底座的 USB 端口,并通过 USB 线将底座连接到 Windows 设备使用,以获取更 佳的用户体验。

Windows[X-input]

· required system: Windows 10 (1903) or above

wireless connection

- 1 connect the 2.4G receiver to the USB port of your Windows device
- 2 turn the mode switch to X
 3 press home button to turn on the controller, wait till the controller is successfully recognized by the system to play, status LED stays solid

wired connection

- 1 turn the mode switch to X
 2 connect the controller to your Windows device via USB cable, wait till the controller is successfully recognized by the system to play, status LED stays solid

Android[D-input]

- Android system needs to be 9.00 or above
 OTG support is required on your Android device, please contact your manufacturer for more information

wireless connection

- 1 connect the **2.4G receiver** to the USB port of your Android device 2 turn the **mode switch** to **D** 3 press **home button** to turn on the controller, wait till the controller is successfully recognized by the system to play, **status LED** stays solid

wired connection

1 - turn the mode switch to D
 2 - connect the controller to your Android device via USB cable, wait till the controller is successfully recognized by your Android device to play, status LED stays solid

Turbo function

- status LED blinks continuously when the button with turbo functionality is pressed.
 D-pad, joysticks are not included
 hold the button you would like to set turbo functionality to, then press the star button to activate/deactivate its turbo functionality

连接 Windows 设备

* 要求 Windows 设备系统版本为 Windows 10 (1903) 或更高版本。

无线连接

- 1. 将配备的 **2.4G 接收器** 连接到 Windows 设备的 USB 端口。
- 2. 将手柄背后的 模式开关 移动到 X 位置。
- 3. 按下 home 键 开启手柄,等待系统识别完成后,状态指示灯 常亮。

有线连接

- 1. 将手柄背后的 模式开关 移动到 X 位置。
- 2. 使用 USB 线将手柄连接到 Windows 设备的 USB 端口,等待系统识别完成后,状态指示灯 常亮。

连接 Android 设备

- * 要求 Android 设备系统版本为 9.0 或更高版本。
- 需要 Android 设备配备 USB 端口且支持 OTG 功能,详情请咨询设备制造商。

无线连接

- 1. 将配备的 **2.4G 接收器** 连接到 Android 设备的 USB 端口。
- 2. 将手柄背后的 **模式开关** 移动到 **D** 位置。
- 3. 按下 home 键 开启手柄,等待系统识别完成后,状态指示灯 常亮。

有线连接

- 1. 将手柄背后的 模式开关 移动到 D 位置。
- 2. 使用 USB 线将手柄连接到 Android 设备的 USB 端口,等待系统识别完成后,状态指示灯 常亮。

连发功能

- * 已开启连发功能的按键,按下时状态指示灯会持续闪烁。
- **方向键、左摇杆、右摇杆** 不支持连发。
- 按住需要设置连发的功能键,再按下星号键可开启/关闭连发。

battery controller status -LED indicator red LED blinks low battery red LFD stays solid battery charging battery fully charged red LED turns off LED indicator charging dock status white LED stays solid battery charging white LFD turns off battery fully charged

- 15 hours of play time with a 480mAh built-in battery pack, rechargeable with 2 hours charging time
 charging time with the controller on the dock is the same as charging via USB cable

电源

手柄电源状态 — 电量不足 正在充电 充电完成

电源指示灯状态 — 红灯闪烁 红灯常亮 红灯熄灭 充电指示灯状态 —

底座电源状态 -正在充电 配备 480mAh 可充电式锂电池,可持续使用约 15 小时,充电时间约 2 小时。

白灯常亮

* 手柄置于底座的充电时长与 USB 充电一致。

Ultimate Software

- press profile switch button to switch between 3 custom profiles. The profile indicator will not light up when
 using the default setting
 it gives you elite control over every piece of your controller: customize button mapping, adjust stick &
 trigger sensitivity, vibration control and create macros with any button combination. Please visit
 support.8bitdo.com for the application

自定义配置

- 配置后可按下配置键切换不同的配置,默认无配置。
- 请访问 app.8bitdo.cn 获取精英软件,可对手柄按键映射、摇杆灵敏度、扳机键灵敏度、振动强度以及 宏等功能进行自定义配置。

₩

Support









