

playmobil®

5426




WARNING: CHOKING HAZARD

Small parts. Not for children under 3 years.

"Ne concerne que les USA"

Wichtige Unterlagen, bitte sorgfältig aufbewahren!
Important: Please keep these instructions for future reference!
Documents importants, à conserver soigneusement!
Belangrijke documenten, bewaar deze zorgvuldig!





- (D) (A) (CH) (L) (B)** Nur Trinkwasser verwenden. Nach dem Spielen austrocknen lassen.
- (USA) (GB) (CDN) (M) (IRL)** Use only tap water. Dry thoroughly after play.
- (F) (CDN) (B) (L) (CH)** N'utiliser que de l'eau potable. Faire sécher après chaque utilisation.
- (E) (MEX)** Utilizar solamente agua potable. Dejar secar antes de guardar.
- (NL) (B)** Enkel drinkbaar water gebruiken. Na het spelen laten drogen.
- (I) (CH)** Usare solo acqua potabile. Asciugare bene dopo ogni uso.
- (P)** Utilizar somente água potável. Deixar secar antes de guardar.
- (DK)** Anvend kun drikkevand. Lad det tørre ud når du er færdig med at lege.
- (N)** Kun drikkevann skal benyttes. Tørk opp etter at leken er ferdig.
- (S) (FIN)** Använd endast dricksvatten. Låt torka efter användandet.
- (FIN)** Käytä ainoastaan juomavettä. Anna kuivua leikin jälkeen.
- (H)** Kérjük kizárólag ivóvizet használnjon! Játék után ajánlott a termék kiszáritása!
- (CZ)** Používat jen pitnou vodu. Po hraní nechat vyschnout.
- (EST)** Kasutada üksnes joogivett! Mängimise järel kuivatada!
- (LV)** Izmantot tikai dzeramo ūdeni. Pēc spēlēšanas ļaut nožūt.
- (LT)** Naudokite tik geriamąjį vandenį. Pažaidus, išdžiovinkite.
- (SLO)** V igračo vlivajte le pitno vodo. Po igri naj se igrača posuši.
- (SK)** Používať iba pitnú vodu. Po hre nechať vyschnúť.
- (PL)** Używać tylko wody pitnej. Po zabawie pozostaw do wyschnięcia.
- (TR) (CY)** Sadece içme suyu kullanınız. Oyundan sonra kurumaya bırakın.
- (GR) (CY)** Χρησιμοποιείτε μόνο νερό βρύσης. Μόλις τελειώσετε, αφήστε το παιχνίδι να στεγνώσει εντελώς.
- (RO)** Se folosește doar apă potabilă. După joacă se lasă să se usuce.
- (BG)** Използвайте само питейна вода. След игра оставете да изсъхне.
- (CN)** 仅使用饮用水。玩耍后要干燥。

1


1





2




2




3





1




2





3




4




5







6







5




6




7




8




9




10



11





30 00 2573




30 00 2583




30 14 6190




30 14 6200



30 23 7350




30 21 7140



30 26 7410

30 20 7462



30 03 2380



30 25 6162




30 25 8542




30 81 6420




30 07 3820




30 08 1270




30 25 8752




30 25 8762




30 25 8722




30 65 1753



30 46 0062




30 25 8772




30 25 8802




30 64 3573




30 21 6003




30 51 1902



30 51 1892



30 51 1862



30 25 8792



30 25 8892



30 46 0072




30 25 8702




30 64 3583




30 64 3593



30 60 2772



30 25 8742



30 25 9512



30 80 7823

210 cm / (82,7 inch)



30 82 8272


430 cm / (169,3 inch)



30 82 1063



30 61 0890



30 51 1762



30 73 2212




30 22 3200



2x 30 25 6572



30 09 8980



30 24 4672



30 80 8843



30 25 8862



30 27 5440



2x 30 24 4760



30 09 4020



30 25 8712



30 25 8872



30 27 5430





30 03 4630



8x 30 25 8782



4x 30 23 7280



Serviceadressen finden Sie in allen Playmobil-Prospekten
 In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.
 Addresses of Customer Service Departments are shown in all Playmobil catalogues
 Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil
 L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil
 Η διεύθυνση του Γραφείου Εξυπηρέτησης Καταναλωτών PLAYMOBIL βρίσκεται σε όλους τους καταλόγους PLAYMOBIL.
 Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil
 pronounce: plāy-mō-bēel