



User Manual

-1-

- 1 x Wireless Keyboard
- 1 x Micro USB Cable
- 1 x User manual
- 1 x Warranty Card

Bluetooth Specification	Bluetooth 5.1
Dimensions	366x125x16.2mm
Operating Range	< 10 meters
Stand- by time	90 days
Charge time	< 2 hours
Uninterrupted Work Time	90 hours
Lithium Battery Capacity	280 mAh
Lithium Battery Life	3 years
Key Life	3 million clicks
Front side of keyboard	ABS
Back side of keyboard	Stainless steel

Diagram illustrating the back of the keyboard with the following components labeled:

- ① Power Switch
- ② Bluetooth Channel 3
- ③ Bluetooth Channel 2
- ④ Bluetooth Channel 1
- ⑤ Caps Lock Indicator
- ⑥ Charging Indicator
- ⑦ Micro Charging Port

-2-

For system of iOS, Android, windows, Mac OS X, use function keys by directly pressing F1~F12 keys; use F1~F12 keys by pressing Fn + F1~F12 keys. The table below describes special key combinations for different operating systems.

-3-

A. How to pair with Bluetooth devices?

Pair with 1st device

Pair with 2st device

Step 1. Press key  5 seconds to enter pairing mode in channel

channel 2 indicator will flash blue and start to search the available Bluetooth

Step 2. On your Bluetooth device, find the Bluetooth name "iClever IC-B Keyboard" and click to connect it.

Step 3. The status indicator will turn to be blue after successfully paired.

b. How to switch among 3 devices that have already connected?
Press key of / / to switch among connected devices.

NOTE:

1. Auto re-connect function. when you turn on the keyboard, it will connect with the last-used device automatically.
2. If connection fails, delete all the pairing records from your device, and follow the above instructions again.

iOS 8 or below: Win + Space
iOS 9 or above: Ctrl + Space
Samsung Android: Shift + Space
Google Android: Ctrl + Space
Windows: Win + Space

As this is a multilingual keyboard, set the language of the device to your desired language before use.

1. For iOS devices only:
Settings > General > Keyboard > Keyboards > Add new keyboard > Select desired language
2. For Samsung Android devices only:
Settings > Controls > Language and input > Samsung Keyboard > Select input languages > Select desired language
3. For Android devices only:
Settings > Language & input > Physical Keyboard > Set up keyboard layouts > Select desired language
4. For Windows devices only:
Control Panel > Clock, Language and Region > Select desired language

- iOS 6.0 and above
- Mac OS X v10.6 to Mac OS X v10.12 and above
- Windows XP / Vista / 7 / 8 / 10, PC computer with a Bluetooth host
- Android 3.0 and above with Bluetooth HID profile (Smartphones and Tablets)

This keyboard is not compatible with Samsung Smart TV (UE37E55500, UE55KU6400U, UE48JU6400), Mac mini and Nokia phones.

The keyboard will enter sleep mode after being idle for 30 minutes. To activate it, press any key and wait for 3 seconds.

1. When battery capacity is lower than 20%, the charging indicator light will keep flashing. It is time to charge.
2. Use the included USB cable for charging. Connect one end to a USB charger, and the other to the keyboard (Output: DC 5V/500mA; USB charger is not included.)
3. In charging mode, the charging indicator light will turn red. Generally, it takes about 2 hours to a fully charge.

I can't pair the keyboard with my device

If you are unable to connect the keyboard to your devices, please try the following:

- Ensure the device you are trying to pair with is Bluetooth compatible.
- Charge keyboard for 10 minutes.
- Delete all the Bluetooth connection records.
- On your devices, turn off the Bluetooth function and turn it on again.
- Minimize the distance between the keyboard and your device as close as possible (30cm).
- Restart the device and try it again.
- Contact us.

NOTE:
if you connect it by Bluetooth adapter, the connection may not be stable.

Some functions on F1~F12 are not working.
Please read above chart of "Keys and Functions".

Keyboard is lagging, repeating or missing when type.
When your device is low on critical resources like RAM and processing power, it may cause the entire system to lag. To avoid it, please release more RAM.

Please charge the keyboard at least 10 minutes, and restart the keyboard and re-connect it again.

For more questions, please free to email support@iclever.com

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.