





NOVA
MESH
SE TG
 4ARGB

Quick Installation Guide



BIOFENIX

NOVA
MESH
SE

NOVA MESH SE -TG 4ARGB

Package Content:

- ➞ NOVA MESH SE TG Case
- ➞ NOVA MESH SE TG Quick Installation Guide
- ➞ Accessory Pack


3 X Motherboard standoff

8 X 3.5"HDD screw


5 X PSU screw

20 X Motherboard Standard Screw


1 X Speaker




NOVA MESH SE TG -4ARGB




Front



Top




Back




Side

Basic Installation

How to remove the right side panel





Remove both thumb screws





Slide the side panels towards the back of the case

How to remove the tempered glass side panel



How to remove the front panel



NOVA MESH SE Package Content:

- ➞ NOVA MESH SE Case
- ➞ NOVA MESH SE Quick Installation Guide
- ➞ Accessory Pack


3 X Motherboard standoff

8 X 3.5"HDD screw

5 X PSU screw


20 X Motherboard Standard Screw

1 X Speaker




- A Front Panel
- B Dust Filter
- C Fan (120mm)
- D Steel Left Side Panel
- E Side Panel
- F Modular Hard Drive Tray


NOVA MESH SE




Front



Top




Back




Side

Basic Installation

How to remove the right side panel




Remove both thumb screws




Slide the side panels towards the back of the case

How to remove the side panel





Remove both thumb screws



Slide the side panels towards the back of the case



How to remove the front panel



How to remove the dust filters



Top Filter

Pull off the magnetic dust filter




PSU Filter


Pull out the PSU filter from the side of the feet







Drive Locations





Installing 2.5" Drives





Installing 3.5" Drives





PSU Installation





Back Fan Installation (120mm)





Front Fan Installation (120mm)




Front Fan Installation (140mm)



Top Fan Installation (120mm)



Control Panel



A . Power Button

B . Reset Button /LED Button

C . USB3.0 Port







D . Microphone Jack

E . Headphone Jack


F . HDD LED

G . Power LED


VGA Card Installation



Remove the 6+6 controller from the case, before you connect the ARGB cable or fan.



How to connect ARGB on the 6+6 controller:



6+6 Controller QIG



6+6 控制器說明書



Nova Mesh SE TG Page



風魅影SE TG 煥彩版

BE INVINCIBLE

WWW.BITFENIX.COM



BitFenix Co., Ltd.

3F, No.79, Sec. 1, Xintai 5th Rd.,

BitFenix Xi Zhi District, New Taipei City, Chinese Taipei .

©2020 BITFENIX Co., Ltd. All Rights Reserved. All trademarks are registered to their respective owners

For the most updated information, please visit our official website : <http://www.bitfenix.com> Ver 1.0 | 2019/05