

Covers for switches/push-buttons
Rocker
with small transparent lens



With symbol.
For flush-mounted push switch.

Order Code : 2CKA001751A1724
Article No. : 1789 LI-21
EAN: 4011395126905