
V·I·V·



TV Stand for Treadmills & Ellipticals

STAND-TV17

Assembly Manual

⚠ WARNING ⚠

If you do not understand these directions, or if you have any doubts about the safety of the installation, please contact our product support team at 309-278-5303 or help@vivo-us.com for further assistance. Check carefully to make sure there are no missing or defective parts. Failure to report missing parts within 30 days may result in denial of free replacement. Improper installation may cause damage or serious injury. Do not use this product for any purpose that is not explicitly specified in this manual. Do not exceed weight capacity. We cannot be liable for damage or injury caused by improper mounting, incorrect assembly or inappropriate use.



WARNING: CHOKING HAZARD

SMALL PARTS - NOT FOR CHILDREN UNDER 3 YEARS. ADULT SUPERVISION IS REQUIRED.



DO NOT EXCEED WEIGHT CAPACITY

FAILURE TO DO SO MAY RESULT IN SERIOUS INJURY.



DANGER: SERIOUS OR FATAL INJURIES CAN OCCUR FROM TIP OVER.

To help prevent tip over:

- Ensure TV is properly anchored to the stand before use around children
- NEVER allow children to stand, climb, or hang on TV stand.

Need Help? We're Here For You

US-Based Customer Support from Trained Professionals

Monday-Friday from 7am-7pm CST
Saturday 8am-4pm CST


Email Us
help@vivo-us.com

Chat with Live Agent
www.vivo-us.com


Give Us a Call
309-278-5303 ext. 1

Assembly Video & Product Info
www.vivo-us.com/products/stand-tv17

Package Contents



A (x1)
Base



B (x2)
Feet



C (x1)
Upper Pole




D (x1)
Lower Pole



E (x1)
VESA Plate



F (x2)
VESA Adapter



G (x2)
VESA Adapter



H (x4)
Foot Pad



I (x1)
Plastic Cover

Included Hardware & Tools




S-A (x8)
M5x10mm Screw



S-B (x8)
M5 Nut



S-C (x2)
M6x50mm Screw



S-D (x5)
M6x65mm
Carriage Bolt



S-E (x9)
M6 Washer



S-F (x7)
M6 Lock Nut



S-G (x1)
M6 Flange Nut



S-H (x4)
M6x12mm Screw



M-A (x4)
M4x14mm Screw



M-B (x4)
M5x14mm Screw



M-C (x4)
M6x14mm Screw



M-D (x4)
M8x20mm Screw



M-E (x4)
M5 Washer



M-F (x4)
M8 Washer



M-G (x8)
Spacer



T-A (x1)
4mm Allen Wrench



T-B (x1)
Wrench

**Some hardware may not be used.*

Tools Needed:



Phillips Screwdriver


Weight Capacity:



Assembly Steps


STEP 1

Thread the Foot Pads **(H)** into the Feet **(B)**.




STEP 2

Place the Base **(A)** onto the Feet **(B)** and align the side holes. Attach using M6x65mm Carriage Bolts **(S-D)** with M6 Washers **(S-E)** and M6 Lock Nuts **(S-F)**. Tighten using Wrench **(T-B)**.




STEP 3

Use the 4mm Allen Wrench **(T-A)** and Wrench **(T-B)** to remove the pre-installed Screws **(C3)**, Nuts **(C4)** and Washers **(C5)** from the Upper Pole **(C)**. Remove the Inner Pole **(C1)**.



STEP 3 - Cont'd
3.1 Side the Plastic Cover **(I)** down the Lower Pole **(D)**.


3.2 Attach the Upper Pole **(C)** to the Lower Pole **(D)** using M6x50mm Screws **(S-C)** with M6 Washers **(S-E)** on both sides and M6 Lock Nuts **(S-F)**. Tighten using 4mm Allen Wrench **(T-A)** and Wrench **(T-B)**.



STEP 4


9 Height Settings


Insert Inner Pole **(C1)** and secure at the desired height using previously removed hardware **(C3, C4, C5)**. Tighten using 4mm Allen Wrench **(T-A)** and Wrench **(T-B)**. The diagram below shows the **VESA Height** for each **Mounting Position**.




STEP 4

Lift up the Pole Cover **(I)** and attach the **Pole Assembly** to the Base **(A)** using M6x12mm Screws **(S-H)** and 4mm Allen Wrench **(T-A)**. Secure using the remaining M6x65mm Carriage Bolt **(S-D)**, M6 Washer **(S-E)**, M6 Lock Nut **(S-F)** and Wrench **(T-B)**.






Ensure the Tilt Bracket is facing the front.




STEP 5

4 VESA Assembly Options

Determine your TV's VESA pattern and follow the appropriate instructions.



VESA Plate Only
1. 75x75mm [See below]
2. 100x100mm [See below]




VESA Plate + VESA Adapters
3. 200x200mm [Page 9]
4. 200x100mm [Page 10]

VESA Plate Only

75x75mm or 100x100mm VESA Pattern

Attach the VESA Plate **(E)** to the back of TV using the appropriate Screws **(M-A or M-B)** with M5 Washers **(M-E)**. Tighten using a Phillips screwdriver.




Ensure the nut is on the top.


Proceed to **STEP 6** on **Page 12**

VESA Plate + VESA Adapters

200x200mm VESA Pattern




Attaching VESA Adapters:
Attach the VESA Adapters **(F,G)** to the VESA Plate **(E)** as shown using M5x10mm Screws **(S-A)** and M5 Nuts **(S-B)**. Tighten using a Phillips screwdriver and Wrench **(T-B)**.




Proceed to **Securing to TV** on **Page 11**

VESA Plate + VESA Adapters

200x100mm VESA Pattern




Attaching VESA Adapters:
Attach the VESA Adapters **(F,G)** to the VESA Plate **(E)** as shown using M5x10mm Screws **(S-A)** and M5 Nuts **(S-B)**. Tighten using a Phillips screwdriver and Wrench **(T-B)**.




Proceed to **Securing to TV** on **Page 11**

Securing to TV

Attach **VESA Plate Assembly** to the back of TV using the appropriate Screws **(M-A thru M-D)** with Washers **(M-E or M-F)**. Spacers **(M-G)** can be used if needed. Tighten using a Phillips screwdriver.





Ensure the nut is on the top.



STEP 6

Use Wrench **(T-B)** to slightly loosen the pre-installed nut on VESA Plate **(E)**. Hook the VESA Assembly onto the Tilt Bracket and re-tighten the nut. Secure by tightening M6 Flange Nut **(S-G)** onto the bottom.






Height Adjustment


Use the 4mm Allen Wrench **(T-A)** and Wrench **(T-B)** to remove the Screws **(C3)**, Nuts **(C4)** and Washers **(C5)** from the Upper Pole **(C)**. Slide the Inner Pole **(C1)** to the desired position and re-install the Screws, Nuts and Washers in the nearest pair of holes.

The diagram below shows the **VESA Height** for each **Mounting Position**.




Forward & Back Tilt Adjustment

Loosen the **Knob** on the side of the Tilt Joint. Adjust as desired and re-tighten.



Side–to–Side Tilt Adjustment

Loosen the M6 Flange Nut **(S-G)** on the bottom of VESA Plate **(E)** using Wrench **(T-B)**. Adjust as desired and re-tighten.



LAST UPDATED: 04/25/25
REV2.1
v1.1



Need Help? **We're Here For You**

Monday-Friday from 7am-7pm CST
Saturday 8am-4pm CST



Email Us
help@vivo-us.com



Chat with Live Agent
www.vivo-us.com



Give Us a Call
309-278-5303 ext. 1



VIVO-us



@vivo_us



@VIVOus



VIVO

FOR MORE GREAT VIVO PRODUCTS,
CHECK OUT OUR WEBSITE AT: WWW.VIVO-US.COM