

Warranty Information

This product has a limited 1 year warranty in North America, Europe, and Australia.
For information on warranty periods in other regions, please contact your reseller or SilverStone authorized distributor.

Warranty terms & conditions

1. Product component defects or damages resulted from defective production is covered under warranty.
Defects or damages with the following conditions will be fixed or replaced under SilverStone Technology's jurisdiction.
a) Usage in accordance with instructions provided in this manual, with no misuse, overuse, or other inappropriate actions.
b) Damage not caused by natural disaster (thunder, fire, earthquake, flood, salt, wind, insect, animals, etc...)
c) Product is not disassembled, modified, or fixed. Components not disassembled or replaced.
d) Warranty mark/stickers are not removed or broken.
Loss or damages resulted from conditions other than ones listed above are not covered under warranty.

2. Under warranty, SilverStone Technology's maximum liability is limited to the current market value for the product (depreciated value, excluding shipping, handling, and other fees). SilverStone Technology is not responsible for other damages or loss associated with the use of product.

3. Under warranty, SilverStone Technology is obligated to repair or replace its defective products. Under no circumstances will SilverStone Technology be liable for damages in connection with the sale, purchase, or use including but not limited to loss of data, loss of business, loss of profits, loss of use of the product or incidental or consequential damage whether or not foreseeable and whether or not based on breach of warranty, contract or negligence, even if SilverStone Technology has been advised of the possibility of such damages.

4. Warranty covers only the original purchaser through authorized SilverStone distributors and resellers and is not transferable to a second hand purchaser.

5. You must provide sales receipt or invoice with clear indication of purchase date to determine warranty eligibility.

6. If a problem develops during the warranty period, please contact your retailer/reseller/SilverStone authorized distributors or SilverStone <http://www.silverstonetek.com>.
Please note that: (i) You must provide proof of original purchase of the product by a dated itemized receipt; (ii) You shall bear the cost of shipping (or otherwise transporting) the product to SilverStone authorized distributors. SilverStone authorized distributors will bear the cost of shipping (or otherwise transporting) the product back to you after completing the warranty service; (iii) Before you send the product, you must be issued a Return Merchandise Authorization ("RMA") number from SilverStone. Updated warranty information will be posted on SilverStone's official website. Please visit <http://www.silverstonetek.com> for the latest updates.

Additional info & contacts

For North America (usasupport@silverstonetek.com)
SilverStone Technology in North America may repair or replace defective product with refurbished product that is not new but has been functionally tested. Replacement product will be warranted for remainder of the warranty period or thirty days, whichever is longer. All power supplies should be sent back to the place of purchase if it is within 30 days of purchase, after 30 days, customers need to initiate RMA procedure with SilverStone Technology in USA by first downloading the "USA RMA form for end-users" form from the below link and follow its instructions.
<http://silverstonetek.com/contactus.php>

For Australia only (support@silverstonetek.com)
Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Please refer to above "Warranty terms & conditions" for further warranty details.

SilverStone Technology Co., Ltd. 12F No. 168 Jiansong Rd., Zhonghe Dist., New Taipei City 235 Taiwan R.O.C. + 886-2-8228-1238
(standard international call charges apply)

For Europe (support.eu@silverstonetek.de)
For all other regions (support@silverstonetek.com)

SilverStone Technology Co., Ltd.

www.silverstonetek.com

support@silverstonetek.com
Issue date: August, 2012
NO: G11216900


PRECISION SERIES
PS08

PS08 SPECIFICATIONS

Model No.	SST-PS08B				
Material	High-strength plastic and meshed front panel				
Motherboard	Micro ATX, MINI-ITX				
Driver Bay	Exposed	5.25" x 2			
	Internal	3.5" x 4, 2.5" x1			
Cooling System	Front	1 x 120mm intake fan 1 x 80mm fan slot			
	Rear	1 x 80mm fan slot or 1 x 92mm fan slot			
Expansion Slot	4				
Front I/O Port	USB 3.0 x 2 audio x 1 MIC x 1				
Power Supply	1 x optional standard PS2(ATX)				
Expansion Card	Compatible up to 14.1 inches in length				
Limitation of CPU cooler	140mm				
Dimension	168mm(W) x 355mm(H) x 401mm(D)				
Extra	Support Kensington locks				

OPTICAL DRIVE INSTALLATION

1. Remove the front panel as indicated in the diagram



DEUTSCH
1. Nehmen Sie die Frontblende wie in der Abbildung gezeigt ab.

FRANÇAIS
1. Retirez le panneau avant tel qu'illustré par le diagramme

ESPAÑOL
1.Retire el panel frontal como se indica en el diagrama

ITALIANO
1. Rimuovere il pannello frontale come indicato nella figura

РУССКИЙ
1. Снимите переднюю панель, как показано на рисунке


한국어
1.그림에 표시된 대로 전면 패널을 제거합니다.

日本語
1.図示されるようにフロントパネルを取り外します。

繁體中文
1請依圖示由面板正面取下擋版

簡体中文
1请依图示由面板正面取下挡版

2. Install your optical drive or 5.25" device as indicated in the diagram.
(Slide in optical drive from the externally and secure with screws)



DEUTSCH
2. Installieren Sie das optische Laufwerk oder 5,25-Zoll-Gerät wie in der Abbildung gezeigt.
(Schieben Sie das optische Laufwerk von außen ein; anschließend mit Schrauben fixieren.)

FRANÇAIS
2. Installez votre lecteur optique ou un périphérique 5,25" comme indiqué dans l'illustration.
(Insérez le disque optique extérieur et sécurisez à les des vis)

ESPAÑOL
2.Instale la unidad óptica o el dispositivo de 5,25" tal y como se indica en el diagrama.
(Inserte el dispositivo óptico desde el exterior y fíjelo con tornillos)

ITALIANO
2. Installare l'unità ottica o il dispositivo da 5,25" come indicato nello schema.
(Inserire dall'esterno l'unità ottica e fissare con viti)

РУССКИЙ
2. Установите оптический привод или 5,25-дюймовое устройство, как показано на схеме.
(Вывдвиньте оптический привод наружу и закрепите винтами)

한국어
2.광학 드라이브나 5.25" 기기들을 다이어그램에 나타난 대로 설치하십시오.
(밖에서 광드라이브를 밀어 넣고 나사로 고정합니다.)


日本語
2.ご使用の光学ドライブあるいは5.25"デバイスを、図の通りに設置します。
(光学ドライブを外側からスライド式に装着してからネジで固定)

繁體中文
2依圖示安裝你的光碟機或5.25吋裝置
(由外部將光碟機推入機身與面板平齊，於兩側鎖上螺絲)

簡体中文
2依图标安装你的光驱或5.25吋装置
(由外部将光驱推入机身与面板平齐，于两侧锁上螺丝)

HARD DRIVE INSTALLATION

Install your hard drive onto the hard drive bracket as indicated in the diagram and secure with screws.



DEUTSCH
Installieren Sie in das 3,5-Zoll-Laufwerk in der Festplattenhalterung.

FRANÇAIS
Insérez votre disque dur 3,5" dans le support de disque dur.

ESPAÑOL
Instale la unidad de 3,5" en el soporte para unidades de disco duro.

ITALIANO
Installare l'unità 3,5" sul supporto disco rigido.

РУССКИЙ
Установите 3,5-дюймовый диск в кронштейн для жесткого диска.

한국어
3.5" 드라이브를 하드 드라이브 브래킷에 장착하십시오.


日本語
ご使用の3.5"ドライブをハードドライブブラケットの上に設置します。

繁體中文
請依圖示將硬碟放入磁架中，再於兩側鎖上螺絲固定

簡体中文
请依图标将硬盘放入磁架中，再于两侧锁上螺丝固定

SSD INSTALLATION

Install 2.5" drive into the bottom of the chassis and secure with screws



DEUTSCH
Installieren Sie das 2,5 Zoll-Laufwerk im unteren Teil des Gehäuses; anschließend mit Schrauben fixieren.

FRANÇAIS
Installez le lecteur 2.5" dans le bas du boîtier et fixez-le avec des vis.

ESPAÑOL
Instale el disco de 2,5" en la parte inferior de la carcasa y fíjelo con tornillos.

ITALIANO
Installare il drive da 2,5" nella parte bassa dello chassis ed assicurarlo alla struttura con le viti in dotazione.

РУССКИЙ
Установите 2,5-дюймовый жесткий диск в нижнюю часть корпуса и закрепите его винтами.

한국어
2.5" 드라이브를 케이스 바닥에 장착한 후 나사로 고정합니다.

日本語
ケース底部に2.5インチドライブを装着し、ネジで固定します。

繁體中文
從機箱底部鎖固四顆螺絲

簡体中文
从机箱底部锁固四颗螺丝