



Diagram illustrating the internal components of the probe, showing the layout of the sensor, battery, and indicator.

- Sensor for Ambient Temp
- Connection Indicator
- Probe Battery Power Indicator
- Booster Battery Power Indicator
- Notch
- Probe
- Sensor for Internal Temp
- S button

**6. Notch:** When the probe is inserted into meat for measuring the meat's internal temperature, the probe must be inserted deep

**Step 1: Download and install the “TempPro” App.**

1) Remove the probe from the booster;

### Step 6: Start Cooking

3. The connection range between the probe and the booster usually can go as far as 400 feet (120 meters) in an open area, it can be dramatically reduced to as short as 10 feet (3 meters) when the probe is inserted into the meat and then the metal cooking appliance is closed. Therefore, we strongly suggest placing the booster as close as possible to the probe when it is inserted in

**\* WARNING FOR ARTIFICIAL CARDIAC PACEMAKER USERS**

Please be aware that a magnet installed inside the device may impact the functionality of your artificial cardiac pacemaker. If you have a pacemaker, we recommend always staying up to 1 foot or 0.3 meter away from the device.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are

This electronic appliance should not be disposed of with normal household waste. Dispose of the unit

Email: [service@temppro.com](mailto:service@temppro.com)  
Monday-Friday: 8:00am-8:00pm (EST)

-12-

