

Jumper Mini Instruction Manual

Congratulations on your purchase of this Jumper Mini! You have chosen a TOGU branded product which is “Made in Germany”! This sports tool was produced in compliance with valid EU norms. It is free of forbidden phthalates and heavy metals.

The Jumper Mini ball-shaped trampoline comes with the tried and tested Dynair technology, enabling optimum distribution of pressure and an extremely dynamic rebound effect (trampoline action). This makes the Jumper Mini eminently suitable for jumping, hopping, coordination and balance exercises. It is made of special material designed for the effective prevention of slipping.

The Jumper Mini is delivered in its deflated state. Before use, please inflate the Jumper Mini like in instructed here:


1) Inflate:

Please inflate the Jumper Mini with the included pump to its optimal size (ca. 18 cm). Before inflating, please be sure that the Jumper Mini has room temperature. Otherwise the product will be overstretched or insufficiently tensioned. Please moisten the needle and lift up the valve between your index finger and your thumb. Then insert the needle carefully and straight and be careful to not puncture the material with the needle. **See Picture.**



2) Deflate:

If the Jumper mini has been overinflated or less tension is required, insert the needle into the valve without the pump. The air will be released through the needle. Pull out the needle when enough air has escaped to get the required size or tension. **See Picture.**



Warnings:

- Screws of the stability plate are tightened with the right turning moment. Please do not tighten yourself!
- Avoid direct sunlight and do not store near sources of heat as this may affect the shape of the Jumper Mini and alter its rebound action.
- Avoid contact with sharp and pointed objects (e.g. glass splinters / stones in soles of shoes) as these can damage the Jumper Mini. Do not throw the Jumper Mini!
- When exercising and bouncing on the Jumper Mini, sufficient clear space should be allowed around the Jumper Mini (the length of the user's body) to prevent injury to the user.
- Always wear trainers when using the Jumper Mini or train barefoot, but never use the product while wearing socks.
- Check the Jumper Mini for signs of damage before use as the product cannot be guaranteed safe for use if damaged.
- The Jumper Mini must be placed on a horizontal, stable and dry floor surface to ensure that the Jumper Mini cannot skid off to one side during use.
- Children should use the Jumper Mini only under supervision of adults.

Care instructions:

The Jumper Mini is designed to be highly durable and hard-wearing. However, from time to time you should clean the Jumper Mini with a mild household detergent. Do not use caustic detergents or cleaning agents containing acid! First and foremost, you should always make sure that the soft anti-skid coating (circular rubber surface on base of Jumper Mini), which gives the Jumper Mini its exceptional stability, is always clean and dry.

Important: Maximum permissible load: 120 kg, Suitable for children from 3 years